

RM 732

Disinfecting cleaner

PRODUCT INFORMATION

Alkaline soap cleaner – bactericide / fungicide

Properties:

- * alkaline cleaning- and disinfectant agent
- * bactericide, fungicide(Candida), limited virucide (Hepatitis B)
- * good cleaning effect
- * to protect surfaces
- * biological decombustible according to OECD
- * applicable manual, with high-pressure and floor scrubber- machines
- * pH- value in concentrate approx. 10
- * clear, yellowish liquid with mild odour

Fields of application:

- * sanitary area
- * food area
- * agriculture
- * kindergartens and schools

tips of use and processing:

	dosing	temperature	reaction time
* manual	1 – 3%	up to 60°C	15 min(3%) to 4 h (1%)
* RM-sprayer	1 – 3%	up to 60°C	15 min(3%) to 4 h (1%)
* FS 2000	1 – 3%	up to 60°C	15 min(3%) to 4 h (1%)
* high-pressure	1 – 3%	up to 60°C	15 min(3%) to 4 h (1%)
* BR- maintenance cleaning	1 - 3%	up to 60°C	15 min(3%) to 4 h (1%)

Concentration and reaction time depend on the degree of germination and on the demand on the degree of determination in the special field of application according to the demands of the DGHM, DVG or the special comparable national institutes.

Example Hepatitis B: 2% - 30 min.

- Please require our certificates regarding this matter! -

Economy:

1 l RM 732 is sufficient for a manual cleaning and disinfection of approx. 50 m² – when 1% dosed by a medium degree of soiling.

Handling:

Put water into a container, add RM 732 under stirring and mix carefully

Remarks:

- * do not allow to dry cleaning agent solutions on surfaces
- * we recommend the altering use with an other cleaning- or disinfection agent (e.g. RM 735), to avoid the forming of resistant bacteria mutants
- * when manual applied, use protective gloves
- * store frost free

RM 732

Disinfecting cleaner

PRODUCT INFORMATION

Attention:

- C Corrosive; R 34 Causes burns
- N Dangerous for the environment; R 50 Very toxic for aquatic organisms
- S 1/2 Keep locked up and out of the reach of children
- S 23 Do not breathe spray
- S 26 In case of contact with eyes, rinse immediately with plenty of water and seek medical advice
- S 28 After contact with skin, wash immediately with plenty of water and seek medical advice.
- S 36/37/39 Wear suitable protective clothing, gloves and eye/face protection
- S 45 In case of accident or if you feel unwell, seek medical advice immediately (show the label where possible)
- S 51 Use only in well-ventilated areas
- S 60 This material and its container must be disposed of as hazardous waste.

Use biocides safely. Always read the label and product information before use!

Certificates:

- * DGHM (Deutsche Gesellschaft für Hygiene und Mikrobiologie)
- * DVG (Deutsche Gesellschaft für Veterinärmedizin)

Further information:

- * Material safety data sheet

Processing:

Object: e.g. toilettes

- * apply RM-solution with the elected tool
- * watch the recommended reaction time resp. let it dry
- * rinse and vacuum again
- * in the food area (surfaces, which contact with food) rinse with drinking water
- * rinse machines after application with clear water